

213-123

CCT Touch Wheel RF Remote Controller

- Apply to dual color(warm white + cool white) LED controller.
- Ultra sensitive color adjustment touch wheel.
- Each remote can match one or more receiver.
- AAAx2 battery powered.
- Operate with LED indicator light.


CE RoHS



Technical Parameters

| Input and Output |                         | Safety and EMC  |                                                   | Environment           |                    |
|------------------|-------------------------|-----------------|---------------------------------------------------|-----------------------|--------------------|
| Output signal    | RF(2.4GHz)              | EMC standard    | EN IEC 55015/EN IEC 61547<br>ETSI EN 301 489-1/-3 | Operation temperature | Ta: -30℃ ~ +55℃    |
| Working voltage  | 3VDC(AAAx2)             |                 |                                                   | Package               |                    |
| Working current  | <5mA                    | Safety standard | EN 61347-1/-2<br>EN 62493                         | Size                  | L140 x W60 x H26mm |
| Standby current  | <10μA                   |                 |                                                   | Gross weight          | 0.088kg            |
| Standby time     | 1 year                  | Radio Equipment | ETSI EN 300 440                                   | Warranty              |                    |
| Remote distance  | 30m(Barrier-free space) | Certification   | CE RoHS                                           | Warranty              | 5 years            |


Mechanical Structures and Installations




Back Holder

Two options are offered for selection, please fix the back holder on the wall with two screws, or adhere the back holder to the wall with paster.

1. Back holder without magnet



2. Back holder with magnet  
(The remote with built-in magnet)



Operation

- When turn on light, the indicator display blue. when turn off light, the indicator display red.
- When touch the color wheel, the indicator will display the same color.
- When press or touch operation is invalid (If the light is off), the indicator display red.
- To extend battery life, no touch or press key operation after a few seconds, the touch wheel will enter sleep state, you need press any key to make touch wheel quit sleep state.

Match Remote Control (two match ways)

End user can choose the suitable match/delete ways. Two options are offered for selection:

Use the controller's Match key

Match:

Short press match key, immediately press on/off key (single zone remote) or zone key (multiple zone remote) of the remote.  
The LED indicator fast flash a few times means match is successful.

Delete:

Press and hold match key for 5s to delete all match,  
The LED indicator fast flash a few times means all matched remotes were deleted.

Use Power Restart


Match:

Switch off the power, then switch on power, repeat again.  
Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 3 times on the remote.  
The light blinks 3 times means match is successful.

Delete:

Switch off the power, then switch on power, repeat again.  
Immediately short press on/off key (single zone remote) or zone key (multiple zone remote) 5 times on the remote.  
The light blinks 5 times means all matched remotes were deleted.

Key Function



 : Short press turn on/off all zone light.

 : Touch to change current zone color temperature.


 : Short press select and turn on zone light, long press 2s turn off zone light.  
Short press multiple zone key fastly, will select multiple zone synchronously.

 : Adjust brightness for current selected zone, short press 10 levels, long press 1-6s for continuous 256 levels adjustment.

 : Short press recall the scene, long press 2s save current state into S1 /2.  
The LED indicator display green when save OK.  
8 zone recall or save synchronously.

Safety Information

1. Read all instructions carefully before you begin this installation.
2. When installing battery, pay attention to the battery positive and negative polarity.  
A long time without the remote control, remove the battery.  
When remote distance becomes smaller and insensitive, replace the battery.
3. If no response from the receiver, please re-match the remote.
4. Gently handle remote, beware of falling.
5. For indoor and dry location use only.



When replacing the batteries, use both hands to remove the back cover of the remote control.