



- Set LED strip chip type. \* + 2 number + \*
  - \*11\*: TM1803
  - \*12\*: TM1809,TM1804,TM1812,UCS1903,UCS1909,UCS1912,SK6813,UCS2903,UCS2909,UCS2912,WS2811,WS2812,WS2813,WS2815,SM16703P
  - \*13\*: TM1829
  - \*14\*: TLS3001,TLS3002
  - \*15\*: GW6205
  - \*16\*: MBI6120
  - \*17\*: TM1814B(RGBW)
  - \*18\*: SK6812(RGBW), WS2813(RGBW),WS2814(RGBW)
  - \*19\*: UCS8904B(RGBW)
  - \*21\*: LPD6803,LPD1101,D705,UCS6909,UCS6912
  - \*22\*: LPD8803,LPD8806
  - \*23\*: WS2801,WS2803
  - \*24\*: P9813
  - \*25\*: SK9822
  - \*31\*: TM1914A
  - \*32\*: GS8206,GS8208
  - \*33\*: UCS2904
  - \*34\*: SM16804
  - \*35\*: SM16825
  - \*36\*: SM16714(RGBW)
  - \*37\*: UCS5603
  - \*38\*: UCS2603
  - \*39\*: SM16714D
  - \*41\*: UCS7604(RGBW)
  - \*42\*: UCS7804(RGBW)
- Set LED strip RGB order. \* + 1 number + \*
  - \*1\*:RGB, \*2\*:RBG, \*3\*:GRB, \*4\*:GBR, \*5\*:BRG, \*6\*:BGR
- Set RGBW LED strip RGB and W order.
  - \*7\*:W after RGB
  - \*9\*:W before RGB

Example: \*1\* + \*7\* set RGBW order, \*1\* + \*9\* set VRGB order.

## Installation Precautions

1. Please read all instructions carefully before starting the installation.
2. When installing the batteries, pay attention to the positive and negative poles of the batteries;
  - please remove the batteries when you don't use the remote control for a long time;
  - please replace the batteries in time when the distance of the remote control becomes smaller or the remote control fails frequently.
3. If the receiver does not respond, repair the remote control.
4. Hold it gently and avoid dropping it.
5. For indoor and dry environments only.
6. Avoid using it in large metal areas or areas with strong electromagnetic waves, otherwise the remote control distance will be affected.